

## **PS9631**

**PS9631** is installed in the SmartSlot™ Interface located on rear of many PS6xxxx UPS made by Powerstar Inc. This is a Plug in card.

This card allows UPS status and alarms be sent via Network to remote PC monitoring UPS status.

SNMP Network card (PS9631) Environmental Monitor SNMP card

- HTTP, HTTPS, IPv4, IPv6, NTP, SMTP, SNMP v1, SNMP v2c, SNMP v3, SSH V1, SSH V2, SSL, TCP/IP, Telnet
- o RJ-45 10/100 Base-T
- o Radius Authentication
- PS9631 adds temperature and <u>humidity reporting</u> & <u>dry contact closures</u> to remotely manipulate customer supplied relays. Customizable input contacts to monitor external devices with PS9810 adapter
- Monitor external temperature and humidity with optional PS9335TH
- Communicate to the UPS with Powerchute<sup>™</sup> software- supplied with each unit either via USB, RS232 or SNMP.
- Windows XP<sup>™</sup> and above includes native drivers for this UPS. Connect a PC with Windows XP<sup>™</sup> or above to USB and Windows will configure itself to work with the UPS for graceful shutdown capability. Free software also available for many other OS (LINUX).
- Monitor many UPS via Network with this PS9631 or *PS9630 (no Environmental Monitoring capability)* cards and available Powerchute software and one monitor PC.

Shipping weight 1 LB.

PS9335TH PS89810





